DT-470-SD Features

- Monotonic temperature response from 1.4 K to 500 K*
- Conformance to standard Curve 10 temperature response curve
- Useful above 60 K in magnetic fields up to 5 T
- The rugged, reliable Lake Shore SD package designed to withstand repeated thermal cycling and minimize sensor self-heating
- Variety of packaging options

DT-471-SD Features

■ Lower priced version of DT-470 with a temperature range of 10 K to 500 K*

DT-414 Features

- Temperature range: 1.4 K to 375 K (calibration up to 325 K)
- Small mass for rapid thermal response
- Non-magnetic package

DT-421 Features

- Temperature range: 1.4 K to 325 K**
- Non-magnetic package
- Exposed flat substrate for surface mounting
- * Calibrated to 500 K, uncalibrated (Curve 10) to 475 K
- ** Calibrated down to 1.4 K, uncalibrated (Curve 10) to 20 K



CAUTION: These sensors are sensitive to electrostatic discharge (ESD). Use ESD precautionary procedures when handling, or making mechanical or electrical connections to these devices in order to avoid performance degradation or loss of functionality.

DT-400 Series Silicon Diodes

DT-470/471 Hermetically Sealed Silicon Diode

The DT-470/471 Silicon Diode temperature sensors incorporate remarkably uniform sensing elements that exhibit precise, repeatable, monotonic temperature response over a wide range. The elements are mounted into rugged, hermetically-sealed packages that have been specifically designed for proper thermal behavior in a cryogenic environment.

The result is a family of sensors with temperature characteristics so predictable, tightly grouped, and stable that the sensors in most applications are routinely interchangeable with one another.

PACKAGING OPTIONS

BO, CO, CU, CY, DI, ET, LR, MT

DT-414 Unencapsulated Silicon Diodes

The Model DT-414 uses the DT-400 bare chip Silicon Diode mounted on a flat substrate. This chip-level sensor offers minimal thermal mass and minimal physical size. Die attachment is with silver epoxy, and the chip is unencapsulated,

DT-414 leavi

leaving the fragile gold wires exposed.

DT-421-HR Miniature Silicon Diode

available without Kovar leads.

The Lake Shore SD Package -

The SD package, with direct sensor-tosapphire base mounting, hermetic seal, and

most rugged, versatile sensors with the

brazed Kovar leads, provides the industry's

best sample to chip connection. Designed

so heat coming down the leads bypasses

the chip, it can survive several thousand

hours at 500 K (depending on model) and

is compatible with most ultra high vacuum

applications. It can be indium soldered to samples. If desired, the SD package is also

The Most Rugged, Versatile


Package in the Industry

The DT-421 miniature Silicon Diode temperature sensor is configured for installation on flat surfaces. The DT-421 sensor package exhibits precise, monotonic temperature response over its useful range. The sensor chip is in direct contact with the epoxy dome, which causes increased voltage at 4.2 K and prevents full range Curve 10 conformity. For use below 20 K, calibration is required.


DT-421-HR

DT-470/471-SD

Typical DT-400 Diode Voltage Values



Typical DT-400 Diode Sensitivity Values



fax: (614) 818-1600

Specifications

Standard curve Curve 10 (see next page)

Recommended excitation $10 \mu A \pm 0.1\%$

Max reverse voltage 40 V

Max current before damage 1 mA continuous or 100 mA pulsed

Dissipation at recommended excitation 17 μ W at 4.2 K; 10 μ W at 77 K; 5 μ W at 305 K

Thermal response time SD: typical <10 ms at 4.2 K; 100 ms at 77 K; 200 ms at 305 K

Use in radiation Recommended for use only in low level radiation – see Appendix B

Use in magnetic field Not recommended for use in magnetic field applications below 60 K. Low magnetic field dependence when used in fields up to 5 tesla above 60 K - see Appendix B

Reproducibility¹ ±10 mK at 4.2 K

¹ Short-term reproducibility data is obtained by subjecting sensor to repeated thermal shocks from 305 K to 4.2 K

Range of Use

	Minimum Limit	Maximum Limit
DT-470-SD	1.4 K	500 K
DT-471-SD	10 K	500 K
DT-414	1.4 K	375 K
DT-421	1.4 K	325 K

Calibrated Accuracy

	Typical sensor accuracy²	Long-term stability³
1.4 K	±12 mK	_
4.2 K	±12 mK	10 mK
10 K	±12 mK	_
77 K	±22 mK	40 mK
300 K	±32 mK	25 mK
500 K	±50 mK	_

 ^{[(}Calibration uncertainty)² + (reproducibility)²]^{0.5} for more information see Appendices B, D, and E
 Long-term stability data is obtained by subjecting sensor to 200 thermal shocks from 305 K to 77 K

SoftCal™ Accuracy

		2 K to 30 K to 30 K to		60 K to 345 K	345 K to 375 K	375 K to 475 K	
2	S ⁴	_	±0.25 K	±0.15 K	±0.25 K	±1.0 K	
3	S	±0.5 K	±0.25 K	±0.15 K	±0.25 K	±1.0 K	

2S: 77 K and 305 K (DT-470-SD, DT-471-SD, and DT-421) 3S: 4.2 K, 77 K, and 305 K (DT-470-SD only)

Standard Curve 10 Tolerance Bands for DT-400 Series Silicon Diodes

Type 470	2 K to 100 K	100 K to 305 K	305 K to 475 K
Band 11	±0.25 K	±0.5 K	±1.0 K
Band 11A	$\pm 0.25\mathrm{K}$	±1% of temp	±1% of temp
Band 12	±0.5 K	±1.0 K	±2.0 K
Band 12A	±0.5 K	±1% of temp	±1% of temp
Band 13	±1.0 K	±1% of temp	±1% of temp

Type	1.4 K to 10 K	10 K to 375 K	375 K to 475 K				
DT-471	Not recommended	±1.5 K or ±1.5% of temp, whichever is greater					
DT-414	±1.5 K or ± whichever	1.5% of temp, is greater	Not recommended				
Туре		20 K to 325 K					
DT-421	± 2.5 K or $\pm 1.5\%$ of temp, whichever is greater						

Temperature Response Data Table (typical)

	DT-470/4	471*/414	DT-421		
	V (volts)	dV/dT (mV/K)	V (volts)	dV/dT (mV/K)	
1.4	1.698	-13.1	_	_	
4.2	1.626	-33.6	1.789	-36	
10	1.42	-28.7	_	_	
77	1.0203	-1.75	1.02	2	
305	0.507	-2.4	0.507	-2.4	

See Appendix G for expanded response table * DT-471 useful range: >10 K

Physical Specifications


	Mass	Lead type	Lead polarity	Sensor materials used
DT-470/ 471-SD	37 mg	2 – gold and nickel plated Kovar	Positive lead on right with package lid up and leads towards user	Sapphire base with alumina body and lid. Molybdenum/manganese metallization on base and lid top with nickel and gold plating. Gold tin solder as hermetic seal. Silicon chip with aluminum metallization.
DT-414	3 mg	2 – gold	Positive lead on left with chip up and leads towards user	DT-414: alumina base with top metallization (0.1 μ m of molybdenum, 0.2 μ m gold) DT-414M: metallization on top and bottom
DT-421	23 mg	2 – platinum ribbon with tinned 60/40 SnPb solder	Positive lead is right-hand ribbon with platinum disk down and leads towards user	Sensing element is mounted to a platinum disk and covered with a dome of Stycast® 2850 epoxy


Typical Magnetic Field-Dependent Temperature Errors⁵ △T/T (%) at B (magnetic induction)


	Package Base Parallel to Field B								
T(K)	T(K) 1T 2T 3T 4T 5T								
4.2	-200	-300	-350	-400	-500				
20	-10	-20	-25	-30	-40				
40	-4	-6	-8	-10	-12				
60	-0.5	-1	-2	-3	-3.5				
80	< 0.1	-0.5	-0.8	-1.1	-1.5				
300	<-0.1	<-0.1	<-0.1	<-0.1	<-0.1				

Pad	Package Base Perpendicular to Field B							
T(K)	1T	2 T	3 T	4 T	5 T			
4.2	-8	-9	-11	-15	-20			
20	-4	-5	-5	-5	-10			
40	-1.5	-3	-4	-5	-5.5			
60	-0.5	-0.7	-0.8	-1	-1.1			
80	-0.1	-0.3	-0.5	-0.6	-0.7			
300	<0.1	0.2	0.5	0.6	0.6			

⁵ To minimize magnetic field-induced temperature errors, the sensor should be oriented so that the package base is perpendicular to the magnetic field flux lines – this results in the diode current being parallel to the magnetic field









fax: (614) 818-1600

⁴ DT-421 SoftCal has a low end temperature limited to 40 K

DT-400 Series Curve 10 Temperature Response Curve




Standard Curve 10 Tolerance Bands for DT-470/471 Silicon Diodes



DT-400 Series Expanded Temperature Response Data Table

All DT-470, DT-471*, DT-414*, and DT-421* Silicon Diodes follow the same Curve 10 standard temperature response curve, which means they can be interchanged with one another routinely in any application utilizing this response curve.

T (K)	Voltage (V)	dV/dT (mV/K)	T (K)	Voltage (V)	dV/dT (mV/K)	T (K)	Voltage (V)	dV/dT (mV/K)	T (K)	Voltage (V)	dV/dT (mV/K)
1.40	1.69812	-13.1	11.5	1.38021	-24.8	38.0	1.09131	-1.77	210.0	0.73238	-2.32
1.60	1.69521	-15.9	12.0	1.36809	-23.7	40.0	1.08781	-1.74	220.0	0.70908	-2.34
1.80	1.69177	-18.4	12.5	1.35647	-22.8	42.0	1.08436	-1.72	230.0	0.68564	-2.35
2.00	1.68786	-20.7	13.0	1.34530	-21.9	44.0	1.08093	-1.72	240.0	0.66208	-2.36
2.20	1.68352	-22.7	13.5	1.33453	-21.2	46.0	1.07748	-1.73	250.0	0.63841	-2.37
2.40	1.67880	-24.4	14.0	1.32412	-20.5	48.0	1.07402	-1.74	260.0	0.61465	-2.38
2.60	1.67376	-25.9	14.5	1.31403	-19.9	50.0	1.07053	-1.75	270.0	0.59080	-2.39
2.80	1.66845	-27.1	15.0	1.30422	-19.4	52.0	1.06700	-1.77	273.15	0.58327	-2.39
3.00	1.66292	-28.1	15.5	1.29464	-18.9	54.0	1.06346	-1.78	280.0	0.56690	-2.39
3.20	1.65721	-29.0	16.0	1.28527	-18.6	56.0	1.05988	-1.79	290.0	0.54294	-2.40
3.40	1.65134	-29.8	16.5	1.27607	-18.2	58.0	1.05629	-1.80	300.0	0.51892	-2.40
3.60	1.64529	-30.7	17.0	1.26702	-18.0	60.0	1.05267	-1.81	305.0	0.50688	-2.41
3.80	1.63905	-31.6	17.5	1.25810	-17.7	65.0	1.04353	-1.84	310.0	0.49484	-2.41
4.00	1.63263	-32.7	18.0	1.24928	-17.6	70.0	1.03425	-1.87	320.0	0.47069	-2.42
4.20	1.62602	-33.6	18.5	1.24053	-17.4	75.0	1.02482	-1.91	330.0	0.44647	-2.42
4.40	1.61920	-34.6	19.0	1.23184	-17.4	77.35	1.02032	-1.92	340.0	0.42221	-2.43
4.60	1.61220	-35.4	19.5	1.22314	-17.4	80.0	1.01525	-1.93	350.0	0.39783	-2.44
4.80	1.60506	-36.0	20.0	1.21440	-17.6	85.0	1.00552	-1.96	360.0	0.37337	-2.45
5.00	1.59782	-36.5	21.0	1.19645	-18.5	90.0	0.99565	-1.99	370.0	0.34881	-2.46
5.50	1.57928	-37.6	22.0	1.17705	-20.6	95.0	0.98564	-2.02	380.0	0.32416	-2.47
6.00	1.56027	-38.4	23.0	1.15558	-21.7	100.0	0.97550	-2.04	390.0	0.29941	-2.48
6.50	1.54097	-38.7	24.0	1.13598	-15.9	110.0	0.95487	-2.08	400.0	0.27456	-2.49
7.00	1.52166	-38.4	25.0	1.12463	-7.72	120.0	0.93383	-2.12	410.0	0.24963	-2.50
7.50	1.50272	-37.3	26.0	1.11896	-4.34	130.0	0.91243	-2.16	420.0	0.22463	-2.50
8.00	1.48443	-35.8	27.0	1.11517	-3.34	140.0	0.89072	-2.19	430.0	0.19961	-2.50
8.50	1.46700	-34.0	28.0	1.11212	-2.82	150.0	0.86873	-2.21	440.0	0.17464	-2.49
9.00	1.45048	-32.1	29.0	1.10945	-2.53	160.0	0.84650	-2.24	450.0	0.14985	-2.46
9.50	1.43488	-30.3	30.0	1.10702	-2.34	170.0	0.82404	-2.26	460.0	0.12547	-2.41
10.0	1.42013	-28.7	32.0	1.10263	-2.08	180.0	0.80138	-2.28	470.0	0.10191	-2.30
10.5	1.40615	-27.2	34.0	1.09864	-1.92	190.0	0.77855	-2.29	475.0	0.09062	-2.22
11.0	1.39287	-25.9	36.0	1.09490	-1.83	200.0	0.75554	-2.31	*Partial confo	rmances	





See the appendices for a detailed description of:

Installation **Uncalibrated sensors** SoftCal™ Calibrated sensors *CalCurve*™ Sensor packages

Ordering Information

Uncalibrated sensor

Step 1: Choose diode series, for example DT-470.

Step 2: Choose package or mounting adapter—if ordering adapter, substitute the adapter suffix for the SD suffix, for example DT-470-CU.

Step 3: Choose tolerance band (if applicable), for example DT-470-CU-11.

Calibrated sensor

Step 1: Choose diode series, for example DT-470.

Step 2: Choose package or mounting adapter—if ordering adapter, substitute the adapter suffix for the SD suffix, for example DT-470-CU-13.

Step 3: Specify the calibration range suffix code after the model number and package suffix, for example DT-470-CU-13-1.4L.

Note: When ordering a DT-470, only Band 13 sensors are calibrated.

DT-470-CU-1	3-1.4L
Diode Thermometry	7
Diode Series —	
Package/Adapter —	
Tolerance Band —	
Calibration————————————————————————————————————	

DT-400 Series	Calibration Range Suffix Codes Numeric figure is the low end of the calibration Letters represent the high end: L=325 K, H=500 K								
Model number	Uncal	28	38	1.4L	1.4H	70L	70H		
DT-414-UN*	-								
DT-414M-UN*	-								
DT-421-HR									
DT-470-SD-11	-								
DT-470-SD-11A	-								
DT-470-SD-12	-								
DT-470-SD-12A	-								
DT-470-SD-13	-								

Woulding adapters are available for use with the OD package. Topiace OD sums with mounting adapter sums										
CO		•	•							
CU, LR, CY, ET, BO, MT	•	•	•	•		•				
CU-HT										
DT-470-DI-13										

Mounting adapters are available for use with the SD package—replace SD suffix with mounting adapter suffix

Model number	Uncal	28	10L	10 H	70L	70H
DT-471-BO, -CU, CY, -ET, -LR, -MT	•	•	•		•	
DT-471-CO, -CU- HT, -SD DT-471-DI	•	•	•	•	•	•
DT-471-DI	•					

^{*}Lake Shore does not warrant mechanical damage to the DT-414

DT-414 handling: fragile assembly—must not be turned over on gold wire bond side—handle by edges of substrate or by 50 µm diameter gold leads; unencapsulated device must not be exposed to moisture or corrosive atmosphere

DT-414M-UN substrate is backside metallized

Note: upper temperature limit package dependent—see Sensor Packages section Other packaging available by special order—please consult Lake Shore

Accessories available for sensors

SN-CO-C1 CO style sensor clamps for SD package **ECRIT** Expanded interpolation table Calibration report on CD-ROM 8000 COC-SEN Certificate of conformance

Accessories suggested for installationsee Accessories section for full descriptions

Indium solder

fax: (614) 818-1600

VGE-7031 varnish Stycast® epoxy Apiezon® grease 90% Pb, 10% Sn solder Phosphor bronze wire Manganin wire







